

CHANGE DATE & TIME ON
SAMSUNG DCS COMPACT, DCS, 50SI, IDCS100, IDCS500, OS7200, & OS7400

Leave handset on the hook
Press **Transfer** Button and dial **200**
Enter password **1234** (default)
Press **1** to enable programming
Press **Transfer** Button

Press **Transfer** Button again and dial **505**
Enter Day, Date, & Time (see below)
 W = Day of the Week (1=Monday, 2=Tuesday, etc.)
 MM = Month, DD = Day, YY = Year
 HH = Hour, MM = Minute (enter in military format)
Press **Transfer** Button to store and exit programming